


INSTALLATION INSTRUCTIONS

Rear Disk Brake Kit

for Honda ATV's

- Do not discard packaging until product has been successfully installed.



Item	Description
A	Disk Brake Assembly
B	Rear Caliper
C	Brake Line Bracket
D	Emergency Brake Bracket
E	Caliper Mount Plate
F	Bearing Housing

(kit contents continue on following page)

Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 8:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday


Read instructions and view illustrations before beginning.

Thank You

For Choosing



(kit contents continued)



2x

M8 LockWasher



2x


Ø16mm Spacer



2x


M10-1.50 Nylock Nut

1x




M6-1.0 x 45mm Lg. HHCS

4x





M10-1.50 x 40mm Lg. FHCS


2x






M8-1.25 x 20mm Lg. FHCS



Reference only; do not assemble at this time







Remove components shown: *Keep all stock components removed.*



Installation: *Do not tighten hardware completely unless noted.*

1. Install supplied O-Ring as shown in Fig. 2.
 2. Install Bearing Housing (F) and Brake Line Bracket (C) with M10 hardware as shown in Figs. 2 - 2a.
 3. Install Caliper Mount Plate (E) to Bearing Housing (F) with M10 hardware as shown in Fig. 3.
 4. Route Cables through Brake Line Bracket (C) as shown in Fig. 4.
 5. Install Disk Brake Assembly (A). See Fig. 5.
 6. Secure Cables to Emergency Brake Bracket (D) with stock hardware. See Fig. 6.
 7. Install Rear Caliper (B) to Caliper Mount Plate (E) with M8 hardware and Spacers as shown in Fig. 7. Spacers install between Rear Caliper (B) and Caliper Mount Plate (E).
 8. Secure Emergency Brake Bracket (D) to Rear Caliper (B) with provided hardware. See Fig. 7.
 9. Secure assembly with stock Nut and Cotter Pin. See Fig. 8.
- Tighten all hardware completely.






Cables through Brake Line Bracket (C)




Fig. 5



Parts Reference


Item	Description
A	Disk Brake Assembly
B	Rear Caliper
C	Brake Line Bracket
D	Emergency Brake Bracket
E	Caliper Mount Plate
F	Bearing Housing

Fig. 6




Loosely connect cables to Emergency Brake Bracket (D) with stock hardware.


1. Install M6 x 45 Bolt through "helix screw" until it protrudes approximately 2.5mm.
2. Install Emergency Brake Bracket (D) and Helix Screw into Rear Caliper (B) and hand tighten Nut.
3. Adjust M6x45 Bolt depth such that the Emergency Brake Bracket (D) is in the correct orientation.
4. Tighten Nut up to Emergency Brake Bracket (D).




replace provided screw with:




M6 x 45mm




Spacers install between Rear Caliper (B) and Caliper Mount Plate (E)





Parts Reference

Item	Description
A	Disk Brake Assembly
B	Rear Caliper
C	Brake Line Bracket
D	Emergency Brake Bracket
E	Caliper Mount Plate
F	Bearing Housing



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.